

DEEP CLEANER

- **DEEP CLEANER** is a strong activating cleaner developed to remove floor wax, polish and difficult stains without harming the floor surface while maintaining the floors natural finish.
- **Deep Cleaner** is recommended to be used after installation to remove scuff marks, floor wax residue and preparing the floor for Nu-Life coating.
- Vacuum the floor first to remove any dust particles.
- Apply to a small area of the floor at a time, approximately 1 to 2 square meters.
- Spray the floor with **Deep Cleaner**.
- Use only a microfibre mop to apply **Deep Cleaner**.
- It is recommended to wash the mop first when new to remove any loose fibres.
- Do not use a sponge mop as the sponge will carry too much water and over wet the floor.
- Spray the floor surface and leave for 3 to 4 minutes for the **Deep Cleaner** to activate and dissolve the residue.
- Remove the residue with a clean mop before the **Deep Cleaner** dries on the floor.
- It is recommended to periodically clean the mop to remove excess polish or wax residue.
- If all the wax on the floor surface is not removed then repeat the above process.
- When completed it is recommended to mop the floor with Zip Clean to restore the floor to its natural finish.
- All timber and laminate floors are sensitive to moisture and the quantity of water used during cleaning maintenance should be kept to a minimum.

